

Sydney  
during January

Plane Azimuth (degrees)	Plane Inclination (degrees)				
	0	10	20	30	40
270	100%	100%	99%	96%	92%
280	100%	100%	99%	97%	93%
290	100%	100%	100%	97%	93%
300	100%	101%	100%	97%	93%
310	100%	101%	100%	97%	93%
320	100%	101%	100%	97%	92%
330	100%	101%	100%	97%	92%
340	100%	101%	100%	97%	91%
350	100%	101%	100%	96%	91%
0	100%	101%	100%	96%	90%
10	100%	101%	100%	96%	91%
20	100%	101%	100%	96%	91%
30	100%	101%	100%	97%	92%
40	100%	101%	100%	97%	92%
50	100%	101%	100%	97%	92%
60	100%	100%	100%	97%	92%
70	100%	100%	99%	96%	92%
80	100%	100%	99%	96%	92%
90	100%	100%	98%	96%	91%

Sydney  
during February

Plane Azimuth (degrees)	Plane Inclination (degrees)				
	0	10	20	30	40
270	100%	101%	100%	97%	94%
280	100%	101%	101%	99%	96%
290	100%	102%	102%	100%	98%
300	100%	103%	103%	102%	99%
310	100%	103%	104%	103%	100%
320	100%	103%	105%	104%	100%
330	100%	104%	105%	104%	101%
340	100%	104%	105%	104%	101%
350	100%	104%	105%	104%	101%
0	100%	104%	105%	104%	100%
10	100%	104%	105%	104%	100%
20	100%	104%	105%	104%	100%
30	100%	103%	105%	103%	100%
40	100%	103%	104%	102%	100%
50	100%	102%	103%	102%	99%
60	100%	102%	102%	100%	97%
70	100%	101%	101%	100%	96%
80	100%	101%	100%	98%	95%
90	100%	100%	99%	96%	92%

Sydney  
during March

Plane Azimuth (degrees)	Plane Inclination (degrees)				
	0	10	20	30	40
270	100%	101%	101%	99%	96%
280	100%	103%	103%	103%	101%
290	100%	104%	106%	106%	105%
300	100%	105%	108%	109%	108%
310	100%	106%	110%	112%	110%
320	100%	107%	112%	114%	113%
330	100%	108%	113%	115%	115%
340	100%	108%	114%	116%	116%
350	100%	108%	114%	117%	117%
0	100%	108%	114%	117%	117%
10	100%	108%	114%	116%	116%
20	100%	108%	113%	115%	115%
30	100%	107%	112%	114%	114%
40	100%	107%	110%	112%	112%
50	100%	105%	108%	110%	109%
60	100%	104%	107%	107%	105%
70	100%	103%	104%	104%	103%
80	100%	102%	102%	101%	98%
90	100%	101%	99%	97%	94%

Sydney  
during April

Plane Azimuth (degrees)	Plane Inclination (degrees)				
	0	10	20	30	40
270	100%	101%	101%	99%	97%
280	100%	103%	105%	105%	104%
290	100%	105%	109%	111%	111%
300	100%	107%	113%	117%	118%
310	100%	109%	117%	121%	123%
320	100%	111%	119%	125%	129%
330	100%	112%	122%	129%	133%
340	100%	113%	124%	132%	136%
350	100%	114%	125%	133%	138%
0	100%	114%	125%	134%	139%
10	100%	114%	125%	133%	138%
20	100%	113%	124%	131%	136%
30	100%	112%	122%	129%	133%
40	100%	111%	119%	125%	128%
50	100%	109%	116%	121%	123%
60	100%	107%	113%	116%	117%
70	100%	105%	109%	111%	111%
80	100%	103%	105%	105%	104%
90	100%	101%	100%	99%	97%

Sydney  
during May

Plane Azimuth (degrees)	Plane Inclination (degrees)				
	0	10	20	30	40
270	100%	102%	102%	101%	99%
280	100%	105%	108%	110%	109%
290	100%	108%	114%	118%	120%
300	100%	111%	120%	126%	130%
310	100%	114%	126%	134%	139%
320	100%	117%	130%	141%	148%
330	100%	118%	134%	146%	155%
340	100%	120%	137%	151%	161%
350	100%	121%	139%	154%	164%
0	100%	121%	139%	155%	165%
10	100%	121%	139%	154%	164%
20	100%	120%	137%	150%	161%
30	100%	118%	134%	146%	155%
40	100%	117%	130%	140%	148%
50	100%	114%	125%	134%	139%
60	100%	111%	120%	126%	130%
70	100%	108%	114%	118%	119%
80	100%	105%	108%	109%	110%
90	100%	101%	102%	101%	99%

Sydney  
during June

Plane Azimuth (degrees)	Plane Inclination (degrees)				
	0	10	20	30	40
270	100%	101%	101%	101%	100%
280	100%	105%	109%	111%	111%
290	100%	109%	115%	120%	123%
300	100%	112%	122%	130%	134%
310	100%	115%	128%	138%	145%
320	100%	118%	134%	146%	156%
330	100%	121%	138%	154%	164%
340	100%	122%	142%	159%	170%
350	100%	123%	144%	162%	174%
0	100%	124%	144%	163%	176%
10	100%	123%	144%	162%	175%
20	100%	122%	142%	159%	171%
30	100%	121%	139%	154%	165%
40	100%	118%	134%	147%	156%
50	100%	116%	129%	139%	146%
60	100%	112%	123%	131%	135%
70	100%	109%	116%	121%	124%
80	100%	105%	109%	111%	112%
90	100%	101%	102%	102%	100%

Sydney  
during July

Plane Azimuth (degrees)	Plane Inclination (degrees)				
	0	10	20	30	40
270	100%	101%	102%	101%	100%
280	100%	105%	109%	111%	111%
290	100%	109%	115%	121%	123%
300	100%	113%	122%	129%	134%
310	100%	115%	128%	137%	144%
320	100%	118%	134%	145%	154%
330	100%	120%	138%	152%	162%
340	100%	122%	141%	156%	167%
350	100%	123%	143%	159%	171%
0	100%	124%	144%	160%	173%
10	100%	123%	143%	159%	171%
20	100%	122%	141%	156%	167%
30	100%	120%	137%	152%	162%
40	100%	118%	134%	145%	154%
50	100%	115%	128%	137%	144%
60	100%	113%	122%	129%	134%
70	100%	109%	115%	121%	123%
80	100%	105%	109%	111%	112%
90	100%	101%	102%	101%	100%

Sydney  
during August

Plane Azimuth (degrees)	Plane Inclination (degrees)				
	0	10	20	30	40
270	100%	101%	101%	99%	97%
280	100%	103%	106%	107%	106%
290	100%	106%	111%	114%	115%
300	100%	109%	116%	120%	123%
310	100%	111%	120%	127%	130%
320	100%	113%	124%	132%	137%
330	100%	115%	127%	136%	143%
340	100%	116%	130%	141%	147%
350	100%	117%	131%	143%	150%
0	100%	117%	132%	143%	150%
10	100%	117%	131%	143%	150%
20	100%	116%	130%	140%	147%
30	100%	115%	127%	136%	143%
40	100%	113%	124%	132%	137%
50	100%	111%	120%	127%	130%
60	100%	109%	116%	120%	123%
70	100%	106%	111%	114%	115%
80	100%	103%	106%	107%	106%
90	100%	101%	101%	99%	98%

Sydney  
during September

Plane Azimuth (degrees)	Plane Inclination (degrees)				
	0	10	20	30	40
270	100%	101%	101%	99%	96%
280	100%	103%	104%	103%	102%
290	100%	104%	107%	108%	108%
300	100%	106%	110%	112%	112%
310	100%	108%	113%	116%	116%
320	100%	109%	115%	118%	120%
330	100%	110%	117%	121%	122%
340	100%	110%	118%	123%	124%
350	100%	111%	119%	124%	126%
0	100%	111%	119%	124%	126%
10	100%	110%	118%	123%	126%
20	100%	110%	117%	122%	123%
30	100%	109%	116%	120%	121%
40	100%	108%	114%	117%	118%
50	100%	107%	111%	114%	114%
60	100%	105%	109%	110%	110%
70	100%	103%	106%	107%	105%
80	100%	102%	103%	102%	100%
90	100%	100%	99%	97%	95%

Sydney  
during October

Plane Azimuth (degrees)	Plane Inclination (degrees)				
	0	10	20	30	40
270	100%	100%	100%	98%	95%
280	100%	101%	102%	100%	98%
290	100%	102%	103%	103%	100%
300	100%	103%	105%	104%	102%
310	100%	104%	106%	106%	104%
320	100%	104%	107%	107%	105%
330	100%	105%	107%	108%	105%
340	100%	105%	108%	108%	106%
350	100%	105%	108%	108%	106%
0	100%	105%	108%	108%	106%
10	100%	105%	108%	108%	105%
20	100%	105%	107%	107%	105%
30	100%	104%	106%	107%	104%
40	100%	104%	105%	106%	103%
50	100%	103%	104%	104%	102%
60	100%	102%	103%	102%	100%
70	100%	101%	102%	100%	98%
80	100%	101%	100%	99%	96%
90	100%	100%	99%	96%	93%

Sydney  
during November

Plane Azimuth (degrees)	Plane Inclination (degrees)				
	0	10	20	30	40
270	100%	101%	100%	97%	94%
280	100%	101%	100%	98%	95%
290	100%	101%	101%	99%	96%
300	100%	102%	101%	99%	96%
310	100%	102%	101%	99%	96%
320	100%	102%	102%	100%	96%
330	100%	102%	101%	99%	95%
340	100%	102%	101%	99%	94%
350	100%	102%	101%	99%	94%
0	100%	102%	101%	99%	93%
10	100%	102%	101%	98%	93%
20	100%	102%	101%	98%	93%
30	100%	101%	101%	98%	94%
40	100%	101%	101%	98%	94%
50	100%	101%	100%	98%	94%
60	100%	101%	100%	98%	94%
70	100%	101%	100%	97%	93%
80	100%	100%	99%	96%	93%
90	100%	100%	98%	95%	91%

Sydney  
during December

Plane Azimuth (degrees)	Plane Inclination (degrees)				
	0	10	20	30	40
270	100%	101%	100%	97%	93%
280	100%	101%	100%	98%	94%
290	100%	101%	100%	98%	93%
300	100%	101%	100%	97%	93%
310	100%	101%	100%	97%	92%
320	100%	101%	100%	96%	91%
330	100%	101%	99%	96%	90%
340	100%	100%	99%	95%	89%
350	100%	100%	98%	94%	88%
0	100%	100%	98%	94%	88%
10	100%	100%	98%	94%	88%
20	100%	100%	98%	94%	88%
30	100%	100%	98%	94%	89%
40	100%	100%	98%	94%	89%
50	100%	100%	98%	95%	90%
60	100%	100%	98%	95%	90%
70	100%	100%	98%	95%	90%
80	100%	100%	98%	95%	90%
90	100%	100%	98%	94%	90%